



Warranty at a Glance - 2025

Masters Series		
1 - 5HP		63 Months Parts and Labor
Maintenance schedule - 36 months for initial service, every 24 months thereafter. See owner's manual.		
Masters Grand Series		
7.5HP		51 Months Parts and Labor
Maintenance schedule - 36 months for initial service, every 24 months thereafter. See owner's manual.		
Masters Decorative Series		
1/2HP (with Upgraded Panel)		51 Months Parts and Labor
		39 Months Parts and Labor
Maintenance schedule - 24 months for initial service, every 24 months thereafter. See owner's manual.		
Galaxy Select Fountains		
10 - 25HP Three-Phase Units		51 Months Parts and Labor
10HP Single Phase Units		39 Months Parts and Labor
Maintenance schedule - See owner's manual.		
Volcano III		
1.5 - 5.5HP		63 Months Parts and Labor
Maintenance schedule - 36 months for initial service, every 24 months thereafter. See owner's manual.		
Volcano II and Hydromax Series		
1/2HP		39 Months Parts and Labor
1.5 - 5.5HP		63 Months Parts and Labor
Maintenance schedule - 36 months for initial service, every 24 months thereafter. See owner's manual.		
Fixed Base Water Feature Fountains		
1/2HP		51 Months Parts and Labor
1 - 5HP		63 Months Parts and Labor
Maintenance schedule - 36 months for initial service, every 24 months thereafter. See owner's manual.		
Night Glow Lighting		
LED 11W, 22W, 35W		36 Months Parts and Labor (all components)
RGBW 40 W and 72W		36 Months Parts and Labor (all components)
Any Lights without an ALC		12 Months Warranty
Land Master Landscape Lighting		
Encompass LED Lights		36 Months Parts and Labor (all components)
Encompass RGBW Lights		36 Months Parts and Labor (all components)
Horizon LED Step Light		36 Months Parts and Labor (all components)
Solstice Transformer		60 Months Parts and Labor (all components)
Cable, Lighting		12 Months Parts and Labor
Electrical Control Panel		
All Voltages (upgraded panel)		39 Months Parts and Labor
AquaAir Ultra		
Compressor** & Cooling Fan		36 Months Parts and Labor
**Vaness and Pistons are considered "Wear Items" and are not covered under the factory warranty, consult factory for assistance		
*Base and Wall Mounted AquaAir units without an enclosure are not UL or cUL listed and carry a 1 year warranty		
Enclosure		Limited Lifetime Warranty (Against Corrosion)
All other Components		60 Months Parts and Labor
Super Sink Tubing		180 Months (Manufacturer Defect)
Valve Box and Remote Manifold		12 Months Parts and Labor
Replacement Compressor		12 Months Parts and Labor
Solar AquaAir Ultra		
Same as above for common Components		
9" Diffuser Assembly		60 Months Parts and Labor
Solar Panels		60 Months Parts and Labor
Electrical Components and Batteries		12 Months(Manufacturer Defect)
Complete Unit and/or Replacement Power Unit (Less Panel and or Cable)		
1/2HP		24 Months Parts and Labor
1-5.5HP		36 Months Parts and Labor
7.5-25HP		24 Months Parts and Labor
Parts		
Parts, mechanical or electrical		12 Months
Cable, all sizes		36 Months
Discontinued Series		
Celestial Fountains		
10 - 25HP		48 Months Parts and Labor
Masters Series		
10HP		48 Months Parts and Labor
Ultimax Series		
1/2HP		24 Months Parts and Labor
1 - 5HP		36 Months Parts and Labor
Electrical Control Panel		
1/2HP MDS Standard Panel		12 Months Parts and Labor
Warranty only applicable for In-Service Units still under purchase warranty period		
Any modifications made to AquaMaster units that have been installed will void the warranty on those units. To protect the Manufacturer's warranty on any Aquamaster Fountains, a trained service provider must do the repairs. Only parts manufactured by and purchased from AquaMaster Fountains are covered by our full warranty.		