Warranty at a Glance - 2026

Masters Series

1 - 5HP	63 Months Parts and Labor

Maintenance schedule - 36 months for intial service, every 24 months thereafter. See owner's manual.

Masters Grand Series

7.5HP	51 Months Parts and Labor

Maintenance schedule - 36 months for intial service, every 24 months thereafter. See owner's manual.

Masters Decorative Series

1/2HP (with Upgraded Panel)	63 Months Parts and Labor
	39 Months Parts and Labor

Maintenance schedule - 24 months for intial service, every 24 months thereafter. See owner's manual.

Galaxy Select Fountains

10 - 25HP Three-Phase Units	51 Months Parts and Labor
10HP Single Phase Units	39 Months Parts and Labor

Maintenance schedule - See owner's manual.

Volcano III

1.5 - 5.5HP	63 Months Parts and Labor

Maintenance schedule - 36 months for intial service, every 24 months thereafter. See owner's manual.

Volcano II and Hydromax Series

1/2HP	39 Months Parts and Labor
1.5 - 5.5HP	63 Months Parts and Labor

Maintenance schedule - 36 months for intial service, every 24 months thereafter. See owner's manual.

Fixed Base Water Feature Fountains

1/2HP	63 Months Parts and Labor
1 - 5HP	63 Months Parts and Labor

Maintenance schedule - 36 months for intial service, every 24 months thereafter. See owner's manual.

Night Glow Lighting

LED	11W, 22W, 35W	36 Months Parts and Labor (all components)
RGBW	40 W and 72W	36 Months Parts and Labor (all components)
Any Lights without an ALC		12 Months Warranty

Land Master Landscape Lighting

Encompass LED Lights	36 Months Parts and Labor (all components)
Encompass RGBW Lights	36 Months Parts and Labor (all components)
Horizon LED Step Light	36 Months Parts and Labor (all components)
Solstice Transformer	60 Months Parts and Labor (all components)
Cable, Lighting	12 Months Parts and Labor

Electrical Control Panel

All Voltages (upgraded panel)	39 Months Parts and Labor

AquaAir Ultra

Compressor** & Cooling Fan	36 Months Parts and Labor

**Vanes and Pistons are considered "Wear Items" and are not covered under the factory warranty, consult factory for assistance

***Base and Wall Mounted AquaAir** units without an enclosure are not UL or cUL listed and carry a 1 year warranty

Enclosure	Limited Lifetime Warranty (Against Corrosion)
All other Components	60 Months Parts and Labor
Super Sink Tubing	180 Months (Manufacturer Defect)
Valve Box and Remote Manifold	12 Months Parts and Labor
Replacement Compressor	12 Months Parts and Labor

Solar AquaAir Ultra

Same as above for common Components

9" Diffuser Assembly	60 Months Parts and Labor
Solar Panels	60 Months Parts and Labor
Electrical Components and Batteries	12 Months(Manufacturer Defect)

Complete Unit and/or Replacement Power Unit (Less Panel and or Cable)

1/2HP	24 Months Parts and Labor
1-5.5HP	36 Months Parts and Labor
7.5-25HP	24 Months Parts and Labor

Parts

Parts, mechanical or electrical	12 Months
Cable, all sizes	36 Months

Discontinued Series

Celestial Fountains

10 - 25HP	48 Months Parts and Labor

Masters Series

10HP	48 Months Parts and Labor

Ultimax Series

1/2HP	24 Months Parts and Labor
1 - 5HP	36 Months Parts and Labor

Electrical Control Panel

1/2HP MDS Standard Panel	12 Months Parts and Labor

Warranty only applicable for In-Service Units still under purchase warranty period

Any modifications made to AquaMaster units that have been installed will void the warranty on those units. To protect the Manufacturer's warranty on any Aquamaster Fountains, a trained service provider must do the repairs. Only parts manufactured by and purchased from AquaMaster Fountains are covered by our full warranty.

International Warranty at a Glance - 2026

Masters Series

1 - 5HP	36 Months Parts and 15 Months Labor

Maintenance schedule - 36 months for intial service, every 24 months thereafter. See owner's manual.

Masters Grand Series

7.5HP	36 Months Parts and 15 Months Labor

Maintenance schedule - 36 months for intial service, every 24 months thereafter. See owner's manual.

Masters Decorative Series

1/2HP (with Upgraded Panel)	24 Months Parts and 15 Months Labor

Maintenance schedule - 24 months for intial service, every 24 months thereafter. See

Volcano III

1.5 - 5.5HP	36 Months Parts and 15 Months Labor

Maintenance schedule - 36 months for intial service, every 24 months thereafter. See owner's manual.

Volcano II and Hydromax Series

1/2HP	24 Months Parts and 15 Months Labor

Maintenance schedule - 36 months for intial service, every 24 months thereafter. See owner's manual.

1.5 - 5.5HP	36 Months Parts and 15 Months Labor

Maintenance schedule - 36 months for intial service, every 24 months thereafter. See owner's manual.

Fixed Base Water Feature Fountains

1/2HP	24 Months Parts and 15 Months Labor

Maintenance schedule - 36 months for intial service, every 24 months thereafter. See owner's manual.

1 - 5HP	36 Months Parts and 15 Months Labor

Maintenance schedule - 36 months for intial service, every 24 months thereafter. See owner's manual.

Night Glow Lighting

LED	11W, 22W, 35W	36 Months Parts and Labor (all components)
RGBW	40 W	36 Months Parts and Labor (all components)
Any Lights without an ALC		12 Months Warranty

Electrical Control Panel

All Voltages (upgraded panel)	36 Months Parts and 15 Months Labor
1/2HP MDS Standard Panel	

AquaAir Ultra

Compressor** & Cooling Fan	12 Months Parts and 15 Months Labor

**Vanes and Pistons are considered "Wear Items" and are not covered under the factory warranty, consult factory for assistance

***Base and Wall Mounted AquaAir** units without an enclosure are not UL or cUL listed and carry a 1 year warranty

Enclosure	Limited Lifetime Warranty (Against Corrosion)
All other Components	60 Months Parts and Labor
Super Sink Tubing	180 Months (Manufacturer Defect)
Valve Box and Remote Manifold	12 Months Parts and Labor
Replacement Compressor	12 Months Parts and Labor

Solar AquaAir Ultra Same as above for common Components

9" Diffuser Assembly	36 Months Parts and 12 MonthsLabor
Solar Panels	36 Months Parts and 12 MonthsLabor
Electrical Components and Batteries	12 Months(Manufacturer Defect)

Replacement Power Unit (Less Panel and or Cable)

1/2HP	12 Months Parts and 12 Months Labor
1-5HP (Masters Series Only)	36 Months Parts and 12 Months Labor
1-5.5HP	24 Months Parts and 12 Months Labor
7.5-25HP	12 Months Parts and 12 Months Labor

Parts Not Sold with Complete Unit

Parts, mechanical or electrical	12 Months
Cable, all sizes	36 Months

Discontinued Series

Celestial Fountains

10 - 25HP	24 Months Parts and 15 Months Labor

Masters Series

10HP	24Months Parts and 15 Months Labor

Ultimax Series

1/2HP	12 Months Parts and 15 Months Labor
1 - 5HP	24 Months Parts and 15 Months Labor

Warranty only applicable for In-Service Units still under purchase warranty period

Any modifications made to AquaMaster units that have been installed will void the warranty on those units. To protect the Manufacturer's warranty on any Aquamaster Fountains, a trained service provider must do the repairs. Only parts manufactured by and purchased from AquaMaster Fountains are covered by our full warranty.